

Early Warning Key Pass Battery Replacement

Thank you for purchasing
LoJack Early Warning®

You've made the smart investment
to protect your vehicle from loss due
to auto theft.

This is a reminder that your system will require regular maintenance to ensure optimum performance. The batteries in your Early Warning Key Passes are designed to last about one year, but we recommend that you change them every six months. Your Key Pass uses a Lithium watch battery (CR-2032), which can be purchased at any retail store that sells batteries.

For your convenience, the instructions on how to change your battery are outlined to the right. This information can also be found in your LoJack Owner's Manual, or at my.lojack.com.

If you have any questions about changing the batteries in your Key Passes, please call us toll-free at 1-800-4-LOJACK. Our staff will be happy to assist you.

Thank you for being a
LoJack Customer.



1. OPEN KEY PASS: If the back of your Key Pass has a screw, use a Phillips head screwdriver to remove the screw. If the back of your Key Pass does not have a screw, insert a small coin into the indented slot on the side of the case. Gently pry apart the two halves of the Key Pass.

2. REMOVE OLD BATTERY: Push the battery out of its holder using a non-metal tool. Notice the + sign on the face of the battery.

3. INSERT NEW BATTERY: The battery MUST be installed with the + sign facing up. The red light on the face of the Key Pass should flash several times immediately after properly installing a battery.

4. CLOSE THE KEY PASS: Reassemble the Key Pass by snapping the two halves of the case together and replacing the screw. If your case has a screw, insert the screw into its hole then tighten the screw until it is just snug.